Monday, February 20, 2023 8:39 PM

Important Headings are Underlined and Bold:

A bullet point indicates a note and NOT a step



- Bullet points may have images along with them to help visually
 - O Bullet points may also have sub-bullet points for a more in-depth explanation

Headings in Bold Also Indicate Important Steps:

- 1. Steps are numbered, every new page starts with Step 1 and so on
 - a. Steps may have sub-steps to add more information
- 2. Steps may also have images to help visually



- 3. **Bold** word in steps indicate a button
- 4. Italicized words in steps indicate input fields or options
- 5. Keyboard Input in Courier New Font
- 6. <u>Underlined</u> words indicate files
- 7. Menu navigation is indicated by the pipe symbol and italic words: Start | Programs | MS Word
- 8. Numbers referencing other steps will be in red(1...2...3)
- 9. Code will be in a textbox in COURIER NEW font

```
#include <stdio.h>
int main(void)
printf("Hello World in C:)");
return 0;
}
```

Installing and Configuring a Samba File Server on Windows Server

Thursday, February 23, 2023 8:21 PM

Installed Samba on Windows Server:


- 1. Opened Server Manager and clicked *Manage* and then *Add Roles and Features* in the top right corner
- 2. In the *Features* window of the Wizard, selected *SMB 1.0/CIFS File Sharing Support* feature and clicked on **Next**
- 3. In the next window, confirmed selections and clicked on Finish


Configured Samba on Windows Server:

- 1. On Windows desktop, searched for Powershell in the Windows search icon
- 2. Right Clicked Powershell and ran as administrator
- 3. Typed Install-WindowsFeature FS-SMB1 to install the FS-SMB1 feature
- **4. Typed** Set-SMbServerConfiguration -EnableSMB1Protocol \$True -Force **to** enable SMBv1 support on the server

Created Samba Shares on Windows Server:

- 1. On Windows desktop, searched for Server Manager using the Windows search icon
- 2. Opened Server Manager and clicked on the File and Storage Options
- 3. In the next window, clicked on Shares option located on the left panel
- 4. In Shares, clicked on Tasks and then New Share
- 5. In the new share wizard, clicked on SMB Share Quick and clicked on Next
- 6. In share location typed C:\Shares as the custom path and clicked on Next
- 7. In share name, named the share as winsmb and clicked on Next
- 8. In the next couple of windows, left the settings on default settings clicked on Next
- 9. In the confirmation window, verified correct settings and clicked on Create





How to Mount Samba Shares on Ubuntu

Thursday, February 23, 2023 9:25 PM

- These steps work the same way for most Debian-based distros
- This will be done on a Kali machine which is based on Debian

Mounted Samba Shares on Kali:

- 1. Logged into Kali with an admin account and opened a terminal
- 2. Entered sudo apt update to update packages
- 3. If packages weren't up to date, used sudo apt upgrade to install the updates
- 4. Installed cifs-utils package by executing sudo apt install cifs-utils

```
(admin@maindomain.com@ kali)-[/mnt]
$ sudo apt install cifs-utils
Reading package lists... Done
Building dependency tree... Done
Reading state information... Done
cifs-utils is already the newest version (2:7.0-2).
```

- 5. Created a directory where shares will be mounted
 - a. Created a directory using the sudo mkdir /mnt/.smb_clientshareserver
- 6. Once directory was created, created a hidden credentials file by executing sudo vi/root/.smbcredentials
 - a. Used .(dot) to hide the file

```
(admin@maindomain.com@kali)-[/mnt]
$ sudo vi /root/.smbcredentials
```

- 7. In the file, entered the following lines:
 - a. Pressed ESC key and typed : wq! to force overwrite and quit

```
username=admin@maindomain.com
password=**********
```

- 8. Made the credentials file read only and only accessible to the root account by executing sudo chmod 400 /root/.smbcredentials
- 9. Finally, executed the mount command to mount the Samba shares onto this machine
- 10. Command used:
 - a. sudo mount -t cifs -o rw,vers=1.0,credentials=/root/.smbcredentials
 //172.16.0.1/winsmb /mnt/smb_clientshareserver

```
(admin@maindomain.com@kali)-[/mnt]

$ sudo mount -t cifs -o rw,vers=1.0,credentials=/root/.smbcredentials //172.16.0.1/winsmb /mnt/smb_clientshareserver
```

```
(admin@maindomain.com@ kali)-[/mnt/smb_clientshareserver]
$ ls
'Important Docs' shareserver winsmb
```

11. Shares were successfully mounted and accessible

Enabled Automount of Shares in Kali:

- 1. Shares mounted on Linux machines will not be present after reboot, these steps fixed such problem
- 2. Opened the fstab file by executing sudo vi /etc/fstab
- 3. Added the following line to the <u>fstab</u> file:
 - a. //172.16.0.1/winsmb /mnt/smb_clientshareserver cifs vers= 1.0,credentials=/root/.smbcredentials
 - b. Saved the file by hitting the ESC key and typing wq!

```
//172.16.0.1/winsmb /mnt/smb_clientshareserver cifs vers=1.0,credentials=/root/.smbcredentials
```


4. Rebooted the system by executing sudo reboot and verified shares were auto mounted by navigating to /mnt/smd clientshareserver

```
—(admin@maindomain.com⊕ kali)-[/mnt/smb_clientshareserver]
—$ ls
4k.jpg 'Important Docs' shareserver winsmb
```


How to Map a Network Drive on a Windows 10 Client

Thursday, February 23, 2023 9:10 PM


- 1. Obtained location of Samba share by navigating to the share in Windows Server File Explorer
 - a. Copied the path to the folder
 - b. Made sure the share is the network path and not the local path




- 2. On a Windows 10 client, used Windows key and S to search for the Run program
 - a. Pasted the path to the share in the field and clicked OK



3. Once share is opened and can be used, right clicked Map network drive



- 4. In Map Network Drive window, selected drive letter and pasted path to share
 - a. Proceeded to click on Finish



5. Navigated to This PC | Network Location to verify that the drive was mapped to this client

