Monday, February 20, 2023 8:39 PM

Important Headings are Underlined and Bold:

A bullet point indicates a note and NOT a step



- Bullet points may have images along with them to help visually
 - O Bullet points may also have sub-bullet points for a more in-depth explanation

Headings in Bold Also Indicate Important Steps:

- 1. Steps are numbered, every new page starts with Step 1 and so on
 - a. Steps may have sub-steps to add more information
- 2. Steps may also have images to help visually



- 3. **Bold** word in steps indicate a button
- 4. Italicized words in steps indicate input fields or options
- 5. Keyboard Input in Courier New Font
- 6. <u>Underlined</u> words indicate files
- 7. Menu navigation is indicated by the pipe symbol and italic words: Start | Programs | MS Word
- 8. Numbers referencing other steps will be in red(1...2...3)
- 9. Code will be in a textbox in COURIER NEW font

```
#include <stdio.h>
int main(void)
printf("Hello World in C:)");
return 0;
}
```

Adding Users to the Sudoers File in Ubuntu


Saturday, February 25, 2023 4:47 PM

- When users initially login with a domain account, they will not have any permissions(including admin domain accounts)
- To add users to the sudoers file, perform these steps:
- 1. Logged into Ubuntu with a local admin account
- $\hbox{\bf 2. \ Opened a terminal and entered $\tt sudo adduser admin@maindomain.com sudo } \\$
 - a. Entered admin password when prompted
- 3. Verified that user was in the sudo group by entering id admin@maindomain.com

Disabled Registry for Domain Users

Saturday, February 25, 2023 7:04 PM


- Windows stores a lot of critical information in the registry
- Messing with some of these registry files may render your PC useless
- 1. In Server Manager, navigated to Tools | Group Policy Management to open the GP editor
- 2. Right clicked the *USERS* folder and selected *Create a GPO in this domain...*
 - a. Named new GPO ${\tt User}$ ${\tt Disable}$ Regedit and clicked ${\tt OK}$
- 3. Right clicked new GPO and selected Edit
 - a. Navigated to *User Configuration | Administrative Templates | System* and selected *Prevent access to registry editing tools*
 - b. In menu, selected Enabled and clicked Apply and then OK
- 4. In a command prompt In Windows Server, ran gpupdate /force to force an update on Group Policy
- 5. Tested the Group Policy in a Windows 10 client
 - a. In the client, ran a gpupdate /force in a command prompt
 - b. Proceeded to restart client
 - c. Logged into Windows 10 client and tried opening the *Registry Editor* by searching for it in the Windows search bar




Applied File System Quotas

Monday, February 27, 2023 11:41 AM


- 1. In Server Manager, clicked on Add Roles and Features and ran the wizard
 - O In the Server Roles sub-menu clicked on *File and Storage Services* dropdown and selected *File Server Resource Manager* and clicked on **Next**
- 2. Continued clicking on **Next** until the Results sub-menu
 - a. Verified installation selections and clicked on Install
- 3. Back in Server Manager, navigated to Tools | File Server Resource Manager
- 4. In File Server Resource Manager, expanded the *Quote Management* menu on the left side and clicked on *Quote Templates*



5. In the Action menu, on the right side clicked on *Create Quota from Template...*




- 6. Configured Quota for the C:\Shares folder
 - a. In the wizard, clicked on *Browse* and navigated to the *C:\Shares* folder which houses all the shared file server
 - b. In the *Derive properties from this quota template* option selected the *200MB Limit with 50MB Extension* and clicked **Create**




7. Verified Quota was created

- a. Navigated to the Quotas sub-menu
- b. Right-clicked the Quotas folder and selected Refresh
- c. Newly created quota should be present



8. Tested Quota

- a. Navigated to C:\Shares folder and created a text file
- b. Filled the text file with redundant contents
- c. Downloaded a high-quality image from Google and added it into the C:\Share folder
- d. Navigated to the Quotas sub-menu
- e. Right-clicked the Quotas folder and selected Refresh
- f. Quota Percentage should have increased




Blocked an Application From Use

Monday, February 27, 2023 1:22 PM

- This method can be used to block any application on a Windows 10 client
- In this example, domain users will have access restricted to the Microsoft Store
- 1. In Server Manager, navigated to Tools | Group Policy Management to open the GP editor
- 2. Expanded domain and right-clicked the *COMPUTERS* folder and selected *Create a GPO in this domain...*
 - a. Named new GPO Computer Disallow Store and clicked OK
- 3. Right-clicked new GPO and navigated to Computer Configuration | Policies | Windows Settings | Security Settings | Software Restriction Policies | Additional Rules
- 4. Created new Rule
 - a. Right-clicked Additional Rules folder and selected New Path Rule...



- b. Pasted the following path in the Path: field
 - i. %programfiles%\WindowsApps\Microsoft.WindowsStore*
- c. Set security level at Disallowed and hit Apply and then OK
- 5. In a command prompt In Windows Server, ran gpupdate /force to force an update on Group Policy
- 6. Tested the Group Policy in a Windows 10 client
 - a. In the client, ran a gpupdate /force in a command prompt
 - b. Proceeded to restart client
 - c. Logged into Windows 10 client and tried opening the *Microsoft Store* by searching for it in the Windows search bar



Enabled Network Discovery Via Firewall

Monday, February 27, 2023 2:12 PM


- Enabled this feature so users can have access to the printer server and network file shares
- 1. In Server Manager, navigated to Tools | Group Policy Management to open the GP editor
- 2. Right-clicked the domain maindomain.com and selected Create a GPO in this domain...
 - a. Added GPO in this location so all OU's obtain Group Policy inheritance
 - b. Named new GPO $\,$ Allow $\,$ Network $\,$ Discovery Firewall and clicked $\,$ OK
 - Group Policy Management

 A Forest: maindomain.com

 Domains

 maindomain.com

 Allow Network Discovery Firewall
- 3. Right clicked new GPO and selected Edit
 - a. Navigated to Computer Configuration | Windows Settings | Security Settings | Windows Firewall with Advanced Security
 - b. Selected Inbound Rules and clicked New Rule...
 - c. In the first window of the wizard, selected *Predefined* and then *Network Discovery,* and then clicked on **Next**
 - d. In Predefined Rules, made sure all rules were checked and clicked on Next
 - e. In the Action screen selected Allow the Connection and then clicked on Finish
 - f. Verified all rules were on by checking *Inbound Rules*



- 4. In a command prompt In Windows Server, ran <code>gpupdate /force to force an update on Group Policy</code>
- 5. Tested the Group Policy in a Windows 10 client
 - a. In the client, ran a gpupdate /force in a command prompt
 - b. Proceeded to restart client
 - c. Logged into Windows 10 client and opened File Explorer
 - d. Navigated to the Network folder and verified devices on the network were discoverable

Redirecting Computer Account to a Specific OU

Monday, February 27, 2023 8:22 PM

• In AD Users and Computers, the default computer account where new clients are automatically added to is the *Computers* container




- There may be a case where one would want to redirect new clients into a new OU when a computer is added into the domain
 - O For example, Computers -> ALL COMPUTERS OU
- In this demonstration, the Computers account will be redirected to the _COMPUTERS OU
- 1. In Server Manager, navigated to Tools | Active Directory Users and Computers
- 2. Right-clicked domain and navigated to New | Organizational Unit
 - a. Named new OU _COMPUTERS and clicked OK
 maindomain.com
 _ADMINS
 _COMPUTERS

Jusers

- 3. Searched for command prompt in the Windows Search Icon and ran as an administrator
- 4. In the terminal, entered redircmp ou=_computers, dc=maindomain, dc=com
 - a. Checked for system message if redirection was successful

```
C:\Windows\system32>redircmp ou=_computers,dc=maindomain,dc=com Redirection was successful.
```

- 5. Returned to Active Directory Users and Computers and refreshed the tool
- 6. Computers account can now be deleted and _COMPUTERS OU is the official new client redirection OU



Deployed Desktop Wallpaper Using a GPO

Tuesday, February 28, 2023 11:15 PM

- 1. In Server Manager, navigated to Tools | Group Policy Management to open the GP editor
- 2. Expanded domain and right-clicked the _USERS folder and selected Create a GPO in this domain...
 - a. Named new GPO User Wallpaper and clicked OK
- 3. Deployed Desktop Wallpaper
 - a. Right-clicked new GPO and navigated to *User Configuration | Policies | Administrative Templates | Desktop*
 - b. Right-clicked *Desktop Wallpaper* and selected *Edit*
 - c. In new window, under *Desktop Wallpaper* selected *Enabled*
 - d. Under Wallpaper Name: pasted the network path to the .jpg file: file \\DC.maindomain.com\winsmb\4k.jpg
 - e. Next to Wallpaper Style: selected the Fill option
 - f. Selected Apply and then OK
- 4. In a command prompt In Windows Server, ran <code>gpupdate /force to force an update on Group Policy</code>
- 5. Tested the Group Policy in a Windows 10 client
 - a. In the client, ran a <code>gpupdate</code> /force in a command prompt
 - b. Proceeded to restart client
 - c. Logged into Windows 10 client and verified wallpaper changes

